

MC33800EKEVME Evaluation Board




Figure 1. MC33800 EVB

Table of Contents

| | | |
|---|-----------------------------------|----|
| 1 | Kit Contents / Packing List | 2 |
| 2 | Important Notice | 3 |
| 3 | Introduction | 4 |
| 4 | Hardware Description | 5 |
| 5 | Software Description | 9 |
| 6 | References | 11 |

1 Kit Contents / Packing List

- Evaluation Board - KIT33800

2 Important Notice

Freescale provides the enclosed product(s) under the following conditions:

This evaluation kit is intended for use of ENGINEERING DEVELOPMENT OR EVALUATION PURPOSES ONLY. It is provided as a sample IC pre-soldered to a printed circuit board to make it easier to access inputs, outputs, and supply terminals. This EVB may be used with any development system or other source of I/O signals by simply connecting it to the host MCU or computer board via off-the-shelf cables. This EVB is not a Reference Design and is not intended to represent a final design recommendation for any particular application. Final device in an application will be heavily dependent on proper printed circuit board layout and heat sinking design as well as attention to supply filtering, transient suppression, and I/O signal quality.

The goods provided may not be complete in terms of required design, marketing, and or manufacturing related protective considerations, including product safety measures typically found in the end product incorporating the goods. Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge. In order to minimize risks associated with the customers applications, adequate design and operating safeguards must be provided by the customer to minimize inherent or procedural hazards. For any safety concerns, contact Freescale sales and technical support services.

Should this evaluation kit not meet the specifications indicated in the kit, it may be returned within 30 days from the date of delivery and will be replaced by a new kit.

Freescale reserves the right to make changes without further notice to any products herein. Freescale makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typical", must be validated for each customer application by customer's technical experts.

Freescale does not convey any license under its patent rights nor the rights of others. Freescale products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale product could create a situation where personal injury or death may occur.

Should the Buyer purchase or use Freescale products for any such unintended or unauthorized application, the Buyer shall indemnify and hold Freescale and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale was negligent regarding the design or manufacture of the part. Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners. © Freescale Semiconductor, Inc. 2008


3 Introduction

The **KIT33800EKEVME** Evaluation Board (EVB) is an easy-to-use circuit board that allows the user to exercise all functions of the MC33800 circuit. The EVB communicates to a PC through a built in USB port. The Freescale SPIGen program provides the User Interface to the MC33800's SPI port and allows the user to send commands to and receive error messages from the IC. The MC33800 contains eight low side drivers (Octal Serial Switch), six General Purpose MOSFET Gate drivers, and two digitally adjustable Constant Current drivers. Six MOSFETs are included on the board to provide a complete working system, capable of driving actual loads directly.

4 Hardware Description

The Hardware Block Diagram is shown below.

MC33800 Evaluation Board Block Diagram



The EVB consists of a 33800 circuit, a USB to SPI interface, a voltage regulator and power conditioning circuit, a set of 9 Input Jumpers, and 3 dual MOSFETS. All 5 volt power required by the EVB is obtained from either the USB, MON08 connectors or the on-board 5 Volt regulator. A 5 position jumper selects which source provides the 5 volt power for VCC (and VDD).

4.1 LED Display

The LED's are provided as a visual output device for the USB-SPI interface. As configured from the factory, LED 2 indicates when power is applied and a USB connection is established, and LED 1 and 3 are tied to the DATA0 and CNTL0 lines, respectively, which can be toggled via the SPIGen program.

4.2 I/O Jumper Definitions (J3) -

The EVB contains nine jumpers that connect the parallel outputs of the USB SPI interface to the ten 33800 inputs as follows:

| USB-SPI Output | 33800 Input | Function |
|----------------|-------------|---------------------|
| DATA0 | PWM1 | Gate Driver 1 Input |
| DATA1 | PWM2 | Gate Driver 2 Input |
| DATA2 | PWM3 | Gate Driver 3 Input |
| DATA3 | PWM4 | Gate Driver 4 Input |
| DATA4 | PWM5 | Gate Driver 5 Input |
| CNTL0 | PWM6 | Gate Driver 6 Input |
| CNTL1 | P1 | OSS 1, 2 Input |
| CNTL2 | P3 | OSS 3, 4 Input |
| CNTL3 | P5 | OSS 5, 6 Input |
| DATA0 | P7 | OSS 7, 8 Input |

Please note: Because there are only 9 parallel signal available from the USB to SPI interface. PWM1 and P7 both share the DATA0 signal. Of course the OSS and Gate Drivers can be controlled by the SPI rather than the parallel inputs to avoid any conflict.

If the user prefers to supply the P1, 3, 5, 7 and PWM1-6 signals externally, other than from the USB-SPI Interface, the jumpers can be removed and connections can be made to the open pins.

4.3 VCC Select Jumper Definitions (JP2) -

JP2 is a 5 pin, 4 position jumper that determines the source of the VCC voltage. The VCC voltage is a 5 volt supply that is used by the USB to SPI MCU and the 33800 (VDD). The 5 volts can be supplied from three different sources:

An internal 5 Volt regulator connected to VBAT (12 Volts)

Directly from the USB Connector

Directly from the on board MON08 connector.

| <u>Jumper Position</u> | <u>VCC Source</u> |
|------------------------|---|
| 1-2 | MON08 Port (used for programming the MCU) |
| 2-3 | USB Port |
| 3-4 | USB Port |
| 4-5 | Internal Voltage Regulator * |

*The factory default is set to the Internal Voltage Regulator position.

4.4 VDD Select Jumper Definitions (JP4)

The VDD jumper is a 3 pin, two position jumper that allows the 33800 to receive 5 volt VDD power from the EVB VCC line or to connect the 33800 VDD line to Ground to demonstrate the “Sleep Mode”. The Normal Operating Setting (factory default) is the VDD to VCC connection, pins 1-2 shorted, pin 3 open.

When JP4 is on pins 2-3, with pin 1 open, the 33800 will be forced into the Sleep Mode. (see data sheet for more information)

4.5 Voltage Regulator Disconnect Jumper (JP1)

The internal voltage regulator can be disconnected from VPWR to allow the 33800 I_{VPWR} to be measured. JP1 normally connects VPWR to the input of the 5 Volt regulator.

4.6 MON08 Connector

The MON08 connector is used to program the USB-SPI MCU, a MCHC908JW32. The source code for the USB-SPI interface is included on the CD to allow reprogramming of the MCU to perform functions not included in the present firmware. The MON08 connector consists of the following 16 pins;

| <u>Pin Number</u> | <u>Name</u> | <u>Description</u> |
|-------------------|-------------|--------------------------------|
| 1 | NC | Unused |
| 2 | GND | VSS (System Gnd) |
| 3 | NC | Unused |
| 4 | RST | Reset |
| 5 | NC | Unused |
| 6 | IRQB | Interrupt Request (Low active) |
| 7 | NC | Unused |
| 8 | NC | Unused |
| 9 | NC | Unused |
| 10 | PTA0 | Port A Bit 0 |
| 11 | NC | Unused |
| 12 | PTA1 | Port A Bit 1 |
| 13 | OSC | 4.9152 MHz Oscillator |
| 14 | PTA2 | Port A Bit 2 |
| 15 | MON08_VCC | +5 Volts from P & E or FSICE |
| 16 | PTC1 | Port C Bit 1 |

This connector mates with the MON08 cable provided with the P & E Cyclone Pro or Freescale FSICEBASE programmer.

4.7 USB Connector

A “B” type USB connector is provided to allow a standard “A to B” USB cable to interconnect the PC to the EVB. The pinout of this connector is as follows:

| <u>Pin Number</u> | <u>Name</u> | <u>Description</u> |
|-------------------|-------------|----------------------|
| 1 | +5 | +5 Volts from the PC |
| 2 | D- | Signal - line |
| 3 | D+ | Signal + line |
| 4 | GND | System ground (VSS) |

4.8 Oscillator Jumper Selects (JP3)

A two position, three pin jumper, labeled JP3 is provided to allow the selection of the clock source for the USB-SPI MCU. JP1 selects the source of the VCC power (+5 volts) in accordance with the following table:

4.9 Position of Oscillator Shorting Jumper Selection Description

Pins 1 & 2 (Pin 3 open) Programming position, Clock = 4.9152 from MON08

Pins 2 & 3 (Pin 1 open) Normal operating position* Clock = 4.000 MHz crystal

*The factory default setting for JP3 is the Normal operating position. To change the programming of the MCU’s flash RAM, this jumper must be moved to the Programming position, the VCC jumper should be set to the MON08 position and the MON08 connector should be attached to the cable from the P & E Cyclone Pro or the Freescale FSICEBASE unit.

4.10 SPI Port Connection Pins

The SPI port is brought out to four pins (SCLK, SI, SO, CSB) on the EVB.

Normally there is no jumpers on these pins, however to verify the proper operation of the SPI interface, the SI and SO pins can be connected via a jumper to allow loopback testing of the USB-SPI interface. Please note that during this loopback mode of operation, the 33800 outputs must be disabled, by setting OUTEN to high or by placing the 33800 in the Sleep Mode by Connecting JP4 to GND.

5 Software Description

There are three main components that comprise the EVB software system.

The firmware that runs on the MCU is a compiled C and assembly language program, that is programmed into the MCU flash RAM.

The user interface software (GUI) that sends USB messages to the EVB, and runs under Windows 2000 or Windows XP, is called the “SPIGen” program, which is written in Visual Basic. 3) The third piece of software is a “device driver” called **spi_usbio.sys** and it interfaces the SPIGen program I/O through the Windows operating system to the USB port on the user’s PC. The device driver interfaces to the Visual Basic program, through a special “wrapper” library called **usbio.com.dll** that translates the Visual Basic COM interface, into the lower level calls in the device driver. These two pieces of software were licensed from Thesycon, a software development company in Germany.

All of the source code that is available is provided on the Installation CD in a folder called “USB_SPI_FINAL”.

For an explanation of the SPIGen program, the user is referred to the documentation that comes with the disk for that program.

5.1 MCU Software Code

The software for the MCU was written in C and HC08 assembly language using the CodeWarrior version 5.0 software integrated development environment (IDE).

Below is a listing of the source code modules and their descriptions:

| | |
|--------------------|--|
| main.c | Beginning module, contains service loop. |
| main.asm | Generated by CodeWarrior, used for additions to main.c written in assembly language. |
| MC68HC908JW32.C | Defines the 16 and 8 Bit Registers |
| constant.c | Random data to fill unused flash RAM |
| isr.c | Interrupt service routine for the timer |
| pll.asm | Sets up the PLL using 4.00 MHz reference frequency |
| spi.c | SPI read and write handlers and initialization routine |
| tb.c | Initializes the time base for the JW32 |
| timer.c | Initializes the timer and PWM output (not used) |
| USB_descriptor.asm | Defines the USB information such as VID, PID, etc. |
| USB_driver.c | Handles USB setup, decode and interrupt service |
| utilities.c | Misc. routines for delay and debug |

The following files are include (header) files to support the above:

| | |
|------------------|--|
| application.h | defines some outputs and some useful macros |
| derivative.h | Generated by CodeWarrior to define the MCU used |
| derivative.inc | Generated by CodeWarrior for COP |
| global.h | Some useful defines for debug |
| jw32_registers.h | More register definitions |
| main_asm.h | header file for main_asm.c |
| MC68HC908JW32.H | Header file for MC68HC908JW32.C |
| motdef.h | General purpose definitions from the old days |
| pll.h | Header file for pll.c |
| spi.h | Header file for spi.c |
| tb.h | Header file for tb.c Timebase |
| timer.h | Header file for timer.c timer initialization |
| usb.h | Header file for USB_driver.c |
| usb_vars.h | Header for variables used in USB_Driver.c |
| utilities.h | Header for utilities.c |
| ansii.lib | c library for ansii c functions |
| Start08.c | Generated by CodeWarrior to define initialization code |
| Project.prm | Defines interrupt and memory map |
| Project.map | Map file generated by compile process |
| Burner.bbl | some defines used in the programming of the JW32 |

5.2 Modifying and Adding to the Software -

To modify and recompile this software, one must download a copy of the CodeWarrior software development suite (IDE) from Freescale. The link to this software is:

<http://www.freescale.com/CodeWarrior>

The USB to SPI software transfers 8 bytes of data from the SPIGen.exe program, via USB, to the MCU. The definitions of the 8 bytes can be found in the main.c program, and the actual transfer and decoding is done in the USB_driver.c program. Comments are provided throughout the code to explain the operation of the individual routines.

Once the code is compiled (without errors), the CodeWarrior IDE provides a means to download the binaries to the P&E Cyclone Pro programmer, via the MON08 port to re-Flash the MCU. The documentation for this process is contained in the CodeWarrior suite of tools and the P&E documentation.

6 References

Following are URLs where you can obtain information on other Freescale products and application solutions:

| Description | URL |
|-----------------------------|--|
| Data Sheet - MC33800 | www.freescale.com/files/analog/doc/data_sheet/MC33800.pdf |
| Freescale's Web Site | www.freescale.com |
| Freescale's Analog Web Site | www.freescale.com/analog |

How to Reach Us:

Home Page:

www.freescale.com

Web Support:

<http://www.freescale.com/support>

USA/Europe or Locations Not Listed:

Freescale Semiconductor, Inc.
Technical Information Center, EL516
2100 East Elliot Road
Tempe, Arizona 85284
1-800-521-6274 or +1-480-768-2130
www.freescale.com/support

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH
Technical Information Center
Schatzbogen 7
81829 Muenchen, Germany
+44 1296 380 456 (English)
+46 8 52200080 (English)
+49 89 92103 559 (German)
+33 1 69 35 48 48 (French)
www.freescale.com/support

Japan:

Freescale Semiconductor Japan Ltd.
Headquarters
ARCO Tower 15F
1-8-1, Shimo-Meguro, Meguro-ku,
Tokyo 153-0064
Japan
0120 191014 or +81 3 5437 9125
support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor China Ltd.
Exchange Building 23F
No. 118 Jianguo Road
Chaoyang District
Beijing 100022
China
+86 10 5879 8000
support.asia@freescale.com

For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center
P.O. Box 5405
Denver, Colorado 80217
1-800-441-2447 or +1-303-675-2140
Fax: +1-303-675-2150
LDCForFreescaleSemiconductor@hibbertgroup.com

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.



Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.

© Freescale Semiconductor, Inc. 2009. All rights reserved.