

Freescale Semiconductor, Inc.

Application Note

Document Number: AN4866

Rev. 0, 01/2014

Coils Used for Wireless Charging

1 Introduction

There are many battery-powered devices, which need to be periodically charged, such as mobile phones, tablets, and battery-powered hand tools. These tools are usually charged by a dedicated cord from a USB port or from a dedicated wall adapter.

Wirelessly transferred power simplifies the charging of these devices and brings more convenience to the everyday lives of our customers. Dedicated controllers are required for wireless charging application control.

Freescale provides the WCT1xxx family of the dedicated controllers for the wireless charging applications. Each type is intended for a certain range of applications in the automotive or industrial and consumer area. Freescale provides the dedicated wireless charging software library intended for these controllers. This library maintains all functions required by the Qi specification.

Contents

1	Introduction	1
2	Coil categories	2
3	Coil description and properties	3
4	A Multicoil solution	5
5	Conclusion	6
6	References	6
7	Revision history	6





2 Coil categories

Each application area requires a certain level of power transfer. The main aspects of the categorization are as follows:

- Transmitter or receiver side:
 - o The transmitter side generates the power electromagnetic field.
 - The receiver side produces the AC/DC current when placed to the power electromagnetic field.
- A level of the transferred power:
 - Low power up to 5 W on the receiver side
 - o Medium power from 5 W to 100 W
 - o High power from 100 W to 1 kW level
 - Very high power more than 1 kW
- Free-positioning:
 - Single coil with or without an attractor
 - Multicoil solution
- Manufacturing:
 - Wire wound from the Litz wire
 - PCB type of coils



3 Coil description and properties

The requirements for the coil construction are as follows:

- The inductance and power capability must meet the category requirements, including the working frequency and transferring power.
- The mechanical dimension must fit to the target application, including the coil area and thickness.
- The coil must provide the electromagnetic shielding for the associated electronic device, such as the mobile phone.
- Durable construction.

Figure 1 shows the basic wire wound coil structure.




Figure 1 Wire wound coil structure (property of TDK)

The coil winding can be one or two layers of the Litz wire. The adhesive tape between coil and ferrite sheet maintains the required distance and the mechanical fixation. The center positioned magnet can be used to provide better alignment between the transmitter and the receiver coils. The ferrite sheet provides the one side magnetic shield and forms the magnetic field. The ferrite properties (material and thickness) have influence to the maximal power transfer for the certain temperature rise.

For the power level 5 W and higher, usually various types of the ferrite material are used. For the power level lower than 5 W, the thin ferrite tape or other soft magnetic materials could be used. The thickness of the magnetic shield is from 0.5 mm to 5 mm depending on the type of coil.



A coil has the following properties:

- Inductance ranging from 6 uH to 27 uH.
- The DC resistance depends mainly on the used type of the Litz wire, usually ranging from 20 m Ω to 100 m Ω .
- The dimension depends on the required power transfer capability and the final application, usually ranging from about 30 mm to 55 mm for the rectangular and the circular single coil.
- The working frequency ranges from 105 kHz to 210 kHz for the devices which meet the Qi specification.
- The working voltage is from 5 V to 50 V in extreme conditions.

Figure 2 shows the examples of the wire wound coils.



Figure 2 Wire wound coils

Figure 3 shows the basic PCB coil structure.




Figure 3 Cross section of the PCB coils system

PCB coils consist of several layers of overlapped coils. All coils are independent and have their own connection points. The coil shapes can vary from the rounded square to hexagonal or circular. The PCB coils usually have higher internal DC resistance, lower quality, lower efficiency, lower thickness, and lower cost. They can be combined with wire wound coils.



4 A Multicoil solution

A multicoil solution is used when the free positioning design is required. The transmitter checks each coil coupling to the receiver, and then selects the coil with the best coupling for the power transfer. It can energize one coil only or several coils together. The simultaneously energized coils can provide higher power transfer capability and larger freedom for the receiver coil placement.

The simultaneously energized coils are connected to the same AC current source with the same electromagnetic field orientation. The connection can be maintained by the power multiplexer or the separate power drivers can be used for each coil. This type of the power transfer, called as one channel transfer, is intended for one receiver only. If you need to charge two or more devices simultaneously, you need to use the multichannel topology. In this case, each channel works independently.

The example of the multicoil design is the Freescale Wireless Charger for automotive sector, topology A13 Rev2. It is controlled by the WCT1001A controller. The final demo example is shown in Figure 4.





Figure 4 Multicoil design example

Figure 5 shows the block schematic of the power multiplexer.




Figure 5 Power multiplexer

The multiplexer is controlled by the wireless charging controller and it can connect one or more coils from the three-coil set to the energy source. The power multiplexer can be spread to more segments to control multicoil. Then one or more coils can be energized simultaneously. This design can be used for all multicoil topologies by the Qi specification.



Figure 6 shows the next possible topology for the multicoil system.




Figure 6 Independent bridge drivers

This topology uses several bridge drivers to energize each coil. The half or full-bridges are controlled by the wireless charging controller. It is possible to energize one or more coils simultaneously. The selection of the final topology depends on the transferring power level and finally on the cost. If a design requires the EMI filter and small frequency range (automotive sector), the multiplexer can be a better selection.

5 Conclusion

The use of the WCT1001A or other controllers from the WCTxxxx family, together with the binary wireless charging library considerably simplifies the whole design process and provides fully tested functions for a reliable application.

6 References

The following reference is available on freescale.com:

Wireless Charging

7 Revision history

Revision number	Date	Substantial changes
0	01/2014	Initial release



How to Reach Us:

Home Page: freescale.com

110000010:0011

Web Support:

freescale.com/support

Information in this document is provided solely to enable system and software implementers to use Freescale products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document.

Freescale reserves the right to make changes without further notice to any products herein. Freescale makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. Freescale does not convey any license under its patent rights nor the rights of others. Freescale sells products pursuant to standard terms and conditions of sale, which can be found at the following address: freescale.com/SalesTermsandConditions.

Freescale and the Freescale logo are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. All other product or service names are the property of their respective owners.

©2014 Freescale Semiconductor, Inc.

